

How to use CK100 auto key programmer to make new car keys:

It is use friendly according to obd2tuning CK100 auto key programmer v45.6 user manual.

Firstly, Prepared two keys, one key can start the engine, another one cannot (blank key) and connected cable to the device.

Secondly, Connected obd2tuning CK100 auto key programmer v45.6 device into the OBD socket.

Next, Turned on obd2tuning CK 100 pin code device.

Following was selecting car model according to obd2tuning V45.6 CK100 instructions.

Then, Inserted a key and turned the console.

Turned ignition on then removed the key.

After that, allowed to add a blank new key while left ignition off.

Waiting for 45 seconds (max 60 seconds) until the safety access procedure was completed.

Finally, blank key has been stored. Tried the second key and the engine can be started by the end.